



INT-TX Transmitters



The transmitter is the central element in the Integrus system. It accepts analogue or digital input, modulates these signals onto carrier waves and transmits these carrier waves to radiators located in the room.

Functions

- Auxiliary mode for distribution of music to all channels during a break
- Slave mode for distribution of signals from another transmitter allows multiple rooms to be used
- Test mode which produces a different frequency tone for each input/channel, with the tone gradually rising as the channels are stepped through
- Adjustable sensitivity for each input to enable fine tuning of audio levels
- Built-in mini infra-red radiator for audio monitoring
- Radiator and system status indication via display
- Each transmitter can be assigned a unique name by the installer for easy identification in a multi-transmitter system
- Each audio channel can also be assigned a unique name by the installer. These names can be selected from a list of options or entered manually
- Automatic distribution of emergency messages to all channels
- Automatic standby/on function
- Automatic synchronization to the number of channels in use in a DCN system
- Universal mains power facility allows use worldwide

- ▶ Can distribute a maximum of 4, 8, 16 or 32 audio channels
- ▶ Can be used with DCN Next Generation, or analogue systems like the CCS 800
- ▶ Flexible configuration of channels and channel quality modes for efficient distribution
- ▶ Configuration of transmitter and system via a display and one single rotary push button

- Stylish 19" (2U) housing for tabletop use or rack mounting
- Handgrips for easy transportation

Controls and Indicators

- 2 x 16 character LCD display for status information and transmitter configuration
- Rotary push button for navigation through menus and configuration
- Power on/off switch on front panel

Interconnections



Interconnections (at rear of transmitter)

- Male Euro socket for mains connection
- Slot with audio data bus connector (H 15, female) for accepting LBB 3422/20 Symmetrical Audio Input and Interpreters Module
- 4, 8, 16 or 32 cinch connectors for input of asymmetrical audio signals

- Two XLR sockets for input of symmetrical signals of floor, emergency messages or music
- One terminal block socket for distribution of emergency messages to all channels
- 3.5 mm (0.14 in) stereo headphone socket for monitoring inputs and channels
- One BNC connector for accepting an HF signal from another transmitter
- Six BNC connectors for output of HF signal to up to 30 radiators
- Two Optical Network Connectors for connection within a DCN Next Generation system*

* LBB 4416/xx Optical Network Cables required

Parts Included

| Quantity | Component |
|----------|---|
| 1 | INT-TX transmitter |
| 1 | 19" rack mounting brackets, detachable feet and mounting accessories for modules included |
| 1 | System installation and operating manual on CD-ROM |
| 1 | Mains cable |

Technical Specifications

Electrical

| | |
|----------------------------|--|
| Mains voltage | 90 to 260 V, 50 to 60 Hz |
| Power consumption | |
| operating, maximum | 55 W |
| standby | 29 W |
| Asymmetrical audio inputs | +3 dBV nominal, +6 dBV maximum (± 6 dB) +15 dBV nominal, +18 dBV maximum (± 6 dB) |
| Symmetrical audio inputs | +6 to +18 dBV nominal |
| Emergency switch connector | emergency control input |
| Headphone output | 32 ohm to 2 kohm |
| HF input | nominal 1 Vpp, minimum 10 mVpp, 75 ohm |
| HF output | 1 Vpp, 6 VDC, 75 ohm |

Mechanical

| Dimensions (H x W x D) | |
|---------------------------------|---|
| for tabletop use, with feet | 92 x 440 x 410 mm (3.6 x 17.3 x 16.1 in) |
| for 19" rack use, with brackets | 88 x 483 x 410 mm (3.5 x 19 x 16.1 in) |
| in front of brackets | 40 mm (1.6 in) |
| behind brackets | 370 mm (14.6 in) |
| Weight | |
| without brackets, with feet | 6.8 kg (15.0 lb) |
| Mounting | brackets for 19" rack mounting or fixing to a tabletop Detachable feet for free-standing on a tabletop |
| Color | charcoal (PH 10736) with silver |

Ordering Information

| | |
|--|-----------------|
| INT-TX04 4-Channel Transmitter 4-channel | INT-TX04 |
| INT-TX08 8-Channel Transmitter 8-channel | INT-TX08 |
| INT-TX16 16-Channel Transmitter 16-channel | INT-TX16 |
| INT-TX32 32-Channel Transmitter 32-channel | INT-TX32 |

Accessories

LBB 3422/20 Symmetrical Audio Input and Interpreter Module **LBB3422/20**
Used for interfacing the transmitter with the CCS 800 discussion systems and the LBB 3222/04 6-Channel Interpreter Desk.

Americas:
Bosch Communications Systems
12000 Portland Avenue South
Burnsville, Minnesota, 55337, USA
Phone: +1-800-392-3497
Fax: +1-800-955-6831
audiosupport@us.bosch.com
www.boschcommunications.us

Europe, Middle East, Africa:
Bosch Security Systems B.V.
P.O. Box 80002
5600 JB Eindhoven, The Netherlands
Phone: +31 40 2577 284
Fax: +31 40 2577 330
emea.securitysystems@bosch.com
www.boschsecurity.com

Asia-Pacific:
Bosch Security Systems Pte Ltd
38C Jalan Pemimpin
Singapore 577180
Phone: +65 6319 3450
Fax: +65 6319 3499
apr.securitysystems@bosch.com
www.boschsecurity.com

Represented by